

POWAPAL

FOR ALL YOUR 12VOLT NEEDS WHILE YOU ARE OUT AND ABOUT



At Powapal we listen to what people need and want in a portable 12v power pack. The mk1 was a big hit with anglers and campers, but some people felt that a USB port was also needed. So we come up with the mk2 which has a 12v aux socket, 1 USB port and a power switch. It also includes the 2.5 mm charger socket on the side which can also be used as a 12v output.

Operating instructions This charger is specially designed for charging the Powapal

- 1) Connect the charger's connector to the Powapal correctly into the 2.5mm socket on the side
- 2) Plug charger into a standard household AC outlet and charging will begin. Please note that a full charge will take up to 12 hours.
- 3) When the battery is charged, the charger will automatically switch to trickle mode.
- 4) When you have finished charging, disconnect the unit from the AC outlet. Then disconnect the Powapal from charger. Never disconnect the battery connector by pulling on the wires.
- 5) Once the charger is disconnected from the AC outlet or the battery is disconnected from the charger, it will be reset automatically and the next charging can be repeated immediately following the above steps.

Made in the UK www.powapal.co.uk email: powapal@gmail.com

